

WiMAX

Part I: PHY

Raj Jain

Professor of CSE

Washington University in Saint Louis

Saint Louis, MO 63130



Jain@cse.wustl.edu

Audio/Video recordings of this lecture are available on-line at:

<http://www.cse.wustl.edu/~jain/cse574-08/>



- What is WiMAX
- Previous Broadband Wireless Access: LMDS, MMDS
- WiMAX PHY Layer
- Frequency Reuse
- Subchannelization
- Frame structure




Key Features of WiMAX

- ❑ Works on many bands: 2.3 GHz, 2.5 GHz, 3.5 GHz, ...
- ❑ Scalable P Can use any available spectrum width: 1.25 MHz to 28 MHz
- ❑ Strong security
- ❑ Open technology like WiFi
- ❑ Reach and mobility like Cellular but much higher data rates
 - High data rate, up to 70Mbps
 - Long distance, up to 50kms
 - Mobility, up to 120 to 150 km/hour
- ❑ Data rate vs Distance trade off using adaptive modulation. 64QAM to BPSK
- ❑ Offers non-line of site (NLOS) operation
- ❑ Strong QoS P Guaranteed services for data, voice, and video

Prior Attempts: LMDS & MMDS

- ❑ Local Multipoint Distribution Service (1998)
 - ❑ 1.3 GHz around 28 GHz band (Ka Band)
28 GHz ⇒ Rain effects
 - ❑ Multi-channel Multipoint Distribution Services (1999-2001)
 - ❑ 2.1, 2.5-2.7 GHz Band ⇒ Not affected by rain
- Issues: Equipment too expensive, Roof top **LoS** antennas, short range (LMDS) or too small capacity (MMDS)



WiMAX

- ❑ WiMAX \neq IEEE 802.16
- ❑ Worldwide Interoperability for Microwave Access
- ❑ 420+ members including Semiconductor companies, equipment vendors, integrators, service providers. Like Wi-Fi Alliance
- ❑ Narrows down the list of options in IEEE 802.16
- ❑ Plugfests started November 2005
- ❑ WiMAX forum lists certified base stations and subscriber stations from many vendors
- ❑ <http://www.wimaxforum.org>

Spectrum Options

Designation	Frequency GHz	Bandwidth MHz	Notes
3.5 GHz	3.4-3.6; 3.3-3.4; 3.6-3.8	200 Total. $2 \times (5 \text{ to } 56)$	Not in US. Considering 3.65-3.70 for unlicensed
2.5 GHz	2.495-2.690	194 Total. 16.5+6 paired.	In USA.
2.3 GHz	2.305-2.320; 2.345-2.360	2×5 paired. 2×5 unpaired.	US, Kr, Au, Nz
2.4 GHz	2.405-2.4835	80 Total	Lic exempt. World-wide.
5 GHz	5.250-5.350; 5.725-5.825	200 MHz	Worldwide.
700 MHz	0.698-0.746; 0.747-0.792	30+48	US
Adv W. Serv.	1.710-1.755; 2.110-2.155	2×45 paired	Used for 3G

Effect of Frequency

- ❑ Higher Frequencies have higher attenuation, e.g., 18 GHz has 20 dB/m more than 1.8 GHz
- ❑ Higher frequencies need smaller antenna
Antenna \geq Wavelength/2, 800 MHz \Rightarrow 6"
- ❑ Higher frequencies are affected more by weather
Higher than 10 GHz affected by rainfall
60 GHz affected by absorption of oxygen molecules
- ❑ Higher frequencies have more bandwidth and higher data rate
- ❑ Higher frequencies allow more frequency reuse
They attenuate close to cell boundaries. Low frequencies propagate far.
- ❑ Mobility \Rightarrow Below 10 GHz

IEEE 802.16 PHYs


	Function	LOS	Freq. Band	Carrier	Duplexing
WirelessMAN SC	Pt-to-pt	LOS	10-66 GHz	Single	TDD, FDD
WirelessMAN SCa	Pt-to-pt	LOS	2-11 GHz Licensed	Single	TDD, FDD
WirelessMAN OFDM (16d)	Pt-to-mpt	NLOS	2-11 GHz Licensed	256	TDD, FDD
WirelessMAN OFDMA (16e)	Pt-to-mpt	NLOS	2-11 GHz Licensed	2048	TDD, FDD
WirelessHUMAN (High-speed Unlicensed)	Pt-to-mpt	NLOS	2-11 GHz License Exempt	1/256/2048	TDD Dynamic Freq. Sel.

IEEE 802.16 PHY: Features

- ❑ Features discussed previously:
 - Scalable OFDMA
 - TDD and FDD
 - Adaptive Modulation and Coding
 - Space Time Block Codes (STBC)
 - Adaptive Antenna System
- ❑ Other Features:
 - Subchannelization and permutation
 - Slots, tiles, and clusters, bursts


Frequency Reuse

- ❑ $N \times S \times K$ frequency reuse pattern
- ❑ N = Number of cells per cluster
- ❑ S = Number of sectors in a cell
- ❑ K = Number of frequency allocations per cell




Frequency Reuse (Cont)


1x3x1




1x3x3




1x1x1




3x1x1



3x3x1




3x3x3




Fractional Frequency Reuse

- Users close to the BS use all frequency subchannels
- Users at the cell boundary use only a fraction of available subchannels




OFDM Subcarriers

- Data subcarriers
- Pilot Subcarriers: Used for channel estimation
- Guard subcarriers: At the edges. No power
- DC subcarrier: At the center for frequency band. No power.



Subchannelization

- Subchannel = Group of subcarriers
- Each user is given one or more subchannel.
- Subcarriers of a subchannel can be contiguous or distributed



- Contiguous
 - ⇒ Subchannels allocated based on use's SINR
 - ⇒ Band AMC ⇒ Not suitable for mobile applications

Subcarrier Permutations

- ❑ Subcarriers are randomly assigned to a channel and changed every symbol time \Rightarrow Frequency hopping
- ❑ All subcarriers are used \Rightarrow Full Usage of Subcarriers (FUSC) – Not in WiMAX Forum Profiles
- ❑ Partial Usage of Subcarriers (PUSC)
 - in WiMAX Forum profiles \Rightarrow commonly used


Downlink Partial Usage of Subcarriers

- ❑ Subcarriers are divided into 6 groups and only some groups may be used in a sector or cell
- ❑ Data and pilots are arranged in clusters of 14 subcarriers over 2 symbols = 24 data + 4 pilot
- ❑ Clusters are renumbered using a pseudo random numbering scheme
- ❑ The clusters are then divided into 6 groups (segments 0 through 5)
- ❑ Subchannel = Two clusters from the same group
- ❑ It is possible to allocate some subset of groups to each transmitter in a cell, e.g., 2 groups per sector

Symbols, Clusters, and Slots (PUSC DL)

10 MHz = 1024 FFT = 840 subcarriers + 1 DC + 183 Guard


Total 30 subchannels = $30 \times 28 = 840$ subcarriers




Symbols, Tiles, and Slots (PUSC UL)

□ 10 MHz = 1024 FFT = 840 subcarriers + 1 DC + 183 Guard

Total 35 subchannels = $35 \times 24 = 840$ subcarriers




802.16 Frame Structure



TDD = Time Division Duplexing
 DL = Downlink (Base to subscriber) FDD = Freq Div Duplexing
 UL = Uplink
 FCH = Frame control header: Burst Profile, Down-link map, Uplink map, DL channel descriptor, etc.


Mobile WiMAX Frame




Frame Structure

- ❑ **DL Preamble:** Time and frequency synchronization
- ❑ **Frame Control Header (FCH):** MAPs lengths, modulation and coding, usable subcarriers
- ❑ **Downlink MAP:** Burst profile (time, frequency, modulation, coding) to each user
- ❑ **Uplink MAP:** Burst profile for transmission from each user. MAPs can be compressed
- ❑ **Contention-based region:** Ranging, bandwidth request, best-effort data
- ❑ **Ranging Channel:**
 - Closed loop frequency, time, and power adjustments
 - Channel quality indicator channel (CQICH)
 - **Ack Channel:** subscriber stations
- ❑ Initially, 5 ms frames only.

Subscriber Initialization



Summary



- ❑ WiMAX supports non-line of sight using scalable OFDMA
- ❑ Any band any bandwidth
- ❑ Sophisticated frequency reuse
- ❑ 2D frame structure

References: Books

1. Cal Eklund, Roger B. Marks, Subbu Ponnuswamy, Kenneth L. Stanwood, Noco J.M. van Waes, "[WirelessMAN: Inside the IEEE 802.16 Standard for Wireless Metropolitan Area Networks](#)," IEEE, May-06, ISBN:0738148423.
2. Jeffrey G. Andrews, Arunabha Ghosh, Rias Muhamed, "[Fundamentals of WiMAX: Understanding Broadband Wireless Networking](#)," Prentice-Hall, ISBN:0132225522.
3. Loutfi Nuaymi, "[WiMAX: Technology for Broadband Wireless Access](#)," Wiley, Mar-07, 310 pp., ISBN:0470028087.

Note: These are the best 3 of 12+ books on WiMAX.